

Download or Print Instructions | Contact: help@mcarbo.com | Page 1



Step 1: Clear your Firearm - Check the chamber, bolt face and magazine well.



Step 2: Gather parts and tools needed for Installation.






. AK-47 Extra Power Recoil Spring

- 2. Bench Block
- 3. Eye Protection

Step 3: To start, Remove the Dust Cover by pushing in the Recoil Assembly (push until you hear a snap).



Step 4: Push forward on the Recoil Spring Assembly and slide out the Factory Spring.





Download or Print Instructions | Contact: help@mcarbo.com | Page 2



Step 5: Place the Button End of the Recoil Spring into the center of the Bench Block.






Step 6: Place one hand in the Middle of the Recoil Spring and the other hand near the top.



Step 7: Push Straight Down until you are Passed the Connection Point On the Guide Rod.





Step 8: Pull up the Guide Rod and Slide it across to Create a T Shape.





Download or Print Instructions | Contact: help@mcarbo.com | Page 3



Step 9: Identify the Recoil Spring Assembly Cap. Gently pry apart
The Guide Rod and Pop Out the Cap.





Step 10: Place the Spring back on the Bench Block and Realign the Guide Rod.



Step 11: Push down on the Bench Block and Slowly allow the Spring to Slide back up (Eye Protection Highly Recommended).



Step 12: Slide the Guide Rod Completely out of the Spring.







Download or Print Instructions | Contact: help@mcarbo.com | Page 4



Step 13: Make sure the Guide Rod Tips are Touching so the New Spring will easily feed through.



Step 14: Feed in the Guide Rod through the Extra Power Recoil Spring.




Step 15: Place the Guide Rod Base back in the Bench Block and Begin to Compress the Spring.





Step 16: Once the Guide Rod reaches the Opening of the Spring, Use a Pick or Mini-Tip Screwdriver to grab the Guide Rod.







Download or Print Instructions | Contact: <u>help@mcarbo.com</u> | Page 5



Step 17: Pull the Guide Rod through the Spring and Slide it across To Create a T Shape (Similar to Step 8).





Step 18: Spread apart the Guide Rod Wire. Re-Attach the Cap by Aligning both Wire Ends with the Two Holes on the Cap.






Step 19: Place the Guide Rod Base back on the Bench Block. Have one Hand Holding the Spring and the other will Straighten out the Guide Rod.





Step 20: Let the Guide Rod slowly feed through your hands and the Spring until Fully Captured.





Download or Print Instructions | Contact: <u>help@mcarbo.com</u> | Page 6



Step 21: Slide the New Recoil Spring Assembly into the AK-47's Bolt Carrier.



Step 22: Compress the Assembly and slide it into the Notches on the Rear Trunnion.





Step 23: Re-Attach the Dust Cover into The Small Notch Shown Below.





Step 24: While Holding Forward on the Dust Cover, Push it Straight Down onto the Recoil Spring. Adjust until the Cover Snaps in Place.







Download or Print Instructions | Contact: <u>help@mcarbo.com</u> | Page 7



Step 25: Perform a Function Check. Check your Slide, Trigger and Safety.

