



M*CARBO KEL-TEC PF-9 / P-32 / P-3AT Stainless Steel Guide Rod



Download or Print Instructions | Contact: help@mcargo.com | Page 1



You must be 18 years of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state. Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.



Step 1: Clear your Firearm - Check the chamber, bolt face and magazine well.

Step 2: Gather Parts and Tools Needed:

- PF9 Stainless Steel Guide Rod
- Bench Block
- Synthetic Grease of PTFE
- 1/8 inch punch
- 3/32 inch punch
- 1/16 inch punch
- Flat head screwdriver
- Hammer
- Flashlight
- Eye protection

Step 3: Remove the takedown pin with your flat head screwdriver.



Step 4: Lock the slide back, and remove the take down pin.



Step 5: Next Remove the slide and you will see your guide rod inside of two recoil springs.



Step 6: Remove the factory guide rod from the springs, making sure the smaller one stays in the middle. Then replace that rod with your new M*CARBO Guide Rod.



Step 7: Reinsert your new guide rod and springs back into the slide, and that will complete the Guide Rod installation.

