

# SUPPORT

---

## Diagram & Parts List

### Micro models

- |                                     |                                    |                             |
|-------------------------------------|------------------------------------|-----------------------------|
| 1. Frame                            | 19. Safety plunger spring          | 37. Firing pin block spring |
| 2. Slide                            | 20. Safety plunger                 | 38. Firing pin block        |
| 3. Disconnecter                     | 21. Right side ambidextrous safety | 39. Front sight             |
| 4. Ejector                          | 22. Slide stop spring              | 40. Rear sight              |
| 5. Grip screw bushing               | 23. Slide stop                     | 41. Barrel                  |
| 6. Grip screw                       | 24. Trigger pad                    | 42. Guide rod               |
| 7. Grip (left)                      | 25. Trigger bar                    | 43. Recoil spring           |
| 8. Grip (right)                     | 26. Trigger bar pin                |                             |
| 9. Hammer pin                       | 27. Trigger spring                 |                             |
| 10. Sear                            | 28. Trigger pin                    |                             |
| 11. Sear pin                        | 29. Over rotation pin              |                             |
| 12. Sear spring                     | 30. Hammer                         |                             |
| 13. Thumb safety                    | 31. Hammer strut                   |                             |
| 14. Magazine release                | 32. Hammer strut pin               |                             |
| 15. Magazine release spring         | 33. Extractor                      |                             |
| 16. Magazine release lock           | 34. Firing pin                     |                             |
| 17. Mainspring housing assembly     | 35. Firing pin spring              |                             |
| 18. Mainspring housing pin retainer | 36. Firing pin stop                |                             |

