



S&W SD9VE / SD40VE

- 1 Frame
- 2 Magazine Catch
- 3 Frame Plug
- 4 Magazine Follower
- 5 Magazine Spring
- 6 Magazine Butt Plate Catch
- 7 Magazine Butt Plate
- 8 Magazine Tube
- 9 Barrel Stop Spring
- 10 Take Down Catch/Barrel Stop
- 11 Ejector
- 12 Sear Housing Block Assembly
- 13 Trigger Bar Assembly
- 14 Locking Block
- 15 Slide Stop Lever Assembly
- 16 Trigger Pin
- 17 Sear Housing Block Assembly Pin
- 18 Safety Plunger Spring
- 19 Striker Safety Plunger
- 20 Extractor
- 21 Striker Assembly
- 22 Extractor Spring Assembly
- 23 Slide End Cap
- 24 Rear Sight
- 25 Front Sight
- 26 Barrel
- 27 Recoil Spring Assembly