



M*CARBO 1911 Pistols Max Control Recoil Springs

Download or Print Instructions | Contact: help@mcarbo.com | Page 1



You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state. Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.

Step 3: Options for the springs:

Step 1: Make sure firearm is clear



1. Lighter loads use the 14 LB Recoil Spring
2. For more common loads use the 16 LB
3. Heavier loads use the 18LB Recoil Spring

If after installing the recoil spring fails to lock back you need to go with a lighter recoil spring



Step 2: Get your M*CARBO 1911 Pistols Max Control Recoil Springs



Step 4: Take a wooden dowel or something none abrasive and push down on the recoil spring plug



Step 5: While the recoil spring plug is being pushed down move the barrel bushing clockwise





M*CARBO 1911 Pistols Max Control Recoil Springs



Download or Print Instructions | Contact: help@mcarbo.com | Page 2

You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state. Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.



Step 6: Slowly ease up on the recoil spring plug (be careful because the plug can jump out)



Step 8: Grab your M*CARBO Recoil Spring and line it up with the recoil spring guide and place the spring in



Step 7: Remove recoil spring



Step 9: Slide your recoil spring plug back on the recoil spring and push down





M*CARBO 1911 Pistols Max Control Recoil Springs



Download or Print Instructions | Contact: help@mcargo.com | Page 3

You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state. Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.



Step 10: While pushing down on the recoil spring plug move the barrel bushing back in place (you can use the dowel for extra help)

Step 12: In case you can't rack the slide back and the spring placed does not work for you refer back to steps 4 through 11 to try one of the other two springs

Step 13: Try them out and see which one you prefer.



Step 11: Test to make sure you can rack the slide and that the spring works for you

