

## M\*CARBO Ruger LCP/LCP II Stainless Steel Guide Rod

Download or Print Instructions | Contact: help@mcarbo.com | Page 1

You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your sta Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any all legal, health and warranty consequences that may be incurred.





Step 1: Make sure firearm is clear



Step 3: Remove the takedown pin




Step 2: Parts & tools you will need:

- ☐ Ruger LCP/LCP II Stainless Steel Guide Rod
- Micro tip flat-head screwdriver





Step 4: Remove factory guide rod from recoil spring





## M\*CARBO Ruger LCP/LCP II Stainless Steel Guide Rod

Download or Print Instructions | Contact: help@mcarbo.com | Page 2







You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state. Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.

Step 5: Insert 316 Stainless Steel replacement into recoil spring and drop down into firearm



Step 7: Make sure hole is completely clear and go in a 45 degree angle. Hit the spring that is there and push it and it drops right in and lock it back



Step 6: Put the slide the back and push back about an eighth of an inch so you can get the takedown pin lined up. Make sure the lugs aren't sticking out and the hole is completely clear



Step 8: You're done with the install. Happy Shooting!

