

Download or Print Instructions | Contact: help@mcarbo.com | Page 1





You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state. Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.



# Step 1: Check Rifle to make sure it is clear



Step 2: Check start trigger pull



#### Step 3: Parts needed

- 1. Trigger Spring Kit
- 2. 1/16 Inch Punch
- 3. ½ Inch Punch
- Flat Head Screwdriver
- 5. Needle nose pliers
- 6. Hammer
- 7. Bench Block
- 8. 2.5 MM Allen Key



9. Eye Protection



Download or Print Instructions | Contact: help@mcarbo.com | Page 2





You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state. Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.



Step 4: Make sure to wear eye protection



Step 6: Make sure the take down pins are extended




Step 8: Put aside the upper and begin to focus on the lower



Step 5: Remove 3 take down pins



Step 7: Separate the lower from the upper





Download or Print Instructions | Contact: help@mcarbo.com | Page 3







You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state.

Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.

Step 9: Remove the bolt stop button on both sides



Step 10: Place 1/16 punch and hammer the punch to have the roll pin come partly out



Step 11: Remove spring from the bolt stop button and repeat process on the other side




Step 12: Remove 16 socket head cap screws with the 2.5 MM Hex Key





Download or Print Instructions | Contact: help@mcarbo.com | Page 4







portion on the safety

Step 13: Keep in mind the square

all legal, health and warranty consequences that may be incurred.




Step 14: Separate both of the bottom halves with a flathead screwdriver and take your time to have everything stay aligned



#### Step 15:

- Hammer Spring
- Linkage
- Hammer
- **Bolt Stop**
- **Ejection Port**





Download or Print Instructions | Contact: help@mcarbo.com | Page 5






You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state.


Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.

#### Step 16:

- Trigger
- Trigger Return Spring (Guide Rod inside spring)
- Trigger Bar
- 4. Trigger Bar spring
- 5. Sear Spring



Step 17: Replace the trigger return spring





Download or Print Instructions | Contact: <a href="mailto:help@mcarbo.com">help@mcarbo.com</a> | Page 6





You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state.

Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.

Step 18: Pull the trigger return spring and it will come right out



Step 19: Grab the M\*CARBO RDB Trigger Spring Kit and place it on the guide rod



Step 20: Compress the trigger return spring before placing it back in





Download or Print Instructions | Contact: help@mcarbo.com | Page 7







Step 21: Place the guide rod and spring back in place, make sure all the coils go back in the trigger ( you can use the flat head as assistance)



Step 22: Drop it back on the notch



#### \*Bonus Step \*

Make sure that the linkage functions evenly and make sure all of the components are in the right spot and in place (Alignment is key)



Step 23: Drop the other half back onto the right portion of the lower n alignment and press on the pins to connect both parts (Make sure you don't have any gaps)





Download or Print Instructions | Contact: help@mcarbo.com | Page 8





You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state.

Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.

Step 24: Make sure the hammer moves forward and backward



Step 25: Take button head cap screw and place first



Step 26: Take safety lever and place it back on the safety with the grip surface facing up (Make sure it is lined up with the square portion)



Step 27: Install all 14 of the socket head cap screws, starting from back to front (Make sure they are snugged)





Download or Print Instructions | Contact: help@mcarbo.com | Page 9






You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state.

Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.



Step 28: Reinstall bolt stopper button, start but push the roll pin to stick up from the bottom, use at first the ½ punch and hammer to push it through then half way through use the 1/16 Punch and make sure the opening of the button is clear






Step 29: Place spring back then place the bolt stopper button back and push the pin through (Repeat step 28 & 29 for the other side)





Download or Print Instructions | Contact: help@mcarbo.com | Page 10







Step 30: Check the bolt stopper button to make sure it moves up and down



Step 31: In case of any misalignment remove the receiver



Step 31: Slide the mag catch back in



Step 32: make sure the piston is located in the buffer






Download or Print Instructions | Contact: help@mcarbo.com | Page 11





You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state. Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.





Step 34: Make sure the star chamber in the bolt it lined up



Step 35: When placing the lower on the upper make sure the pins on the lower are extended outward and your hammer is forward





Download or Print Instructions | Contact: help@mcarbo.com | Page 12







Step 36: Get the forward pin the locate first



Step 37: Compress the lower back into place with the upper



Step 39: Once pins go through make sure to push them in all the way



Step 38: Use the weight of the firearm to help with lining up the holes, once lined up the pins will go right through (In case any trouble you can use one of the punches to help line up the pins)





Download or Print Instructions | Contact: help@mcarbo.com | Page 13





You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state.

Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.

Step 40: After putting the RDB back together, do a quick functions test.

- Charge it,
- Place it on safe
- Pull the trigger
- Place it on fire
- Pull the trigger and keep it depressed
- Charge it again
- Release the trigger and listen for the clicking sound



Step 41: Check the trigger pull and HAPPY SHOOTING!

